


Using the ActivPen



- 01.** Left-click - Tap the pen nib firmly but quickly on the ActivBoard. Example: To select an object.
- 02.** Right-click - Hover the pen over the ActivBoard, less than 5mm away from the board and press the button. Example: To show the 'Object Edit Menu'.
- 03.** Click and drag - Click on the object you want to move, hold the pen nib down on the board and then move the pen. Example: To move objects around the page.
- 04.** Double-click - Two firm but quick taps with the ActivPen's nib performs the same action as double-clicking with a mouse. Example: Double clicking on a text object allows you to edit it.

